

subaru wrx fuse box diagram

Subaru WRX fuse box diagram is a crucial aspect for any WRX owner who wishes to maintain their vehicle's electrical system effectively. Understanding the layout and function of the fuse box can save time and money when troubleshooting electrical issues. The fuse box serves as the central hub for all the electrical components in your Subaru WRX, ensuring that the electrical circuits are protected from overloads. In this article, we will delve into the various components of the Subaru WRX fuse box, its functionality, and how to interpret the fuse box diagram.

Understanding the Fuse Box in Subaru WRX

The fuse box in your Subaru WRX is designed to protect the electrical circuits from damage due to excessive current flow. When an electrical component draws too much current, the fuse will blow, cutting off the power supply and preventing further damage. This is why understanding the fuse box and its layout is essential for effective vehicle maintenance.

Location of the Fuse Boxes

The Subaru WRX typically contains more than one fuse box. Knowing their locations is the first step in understanding your vehicle's electrical system.

1. **Engine Compartment Fuse Box:** Located near the battery, this fuse box houses fuses for critical components such as the engine control unit (ECU) and relays for the fuel pump.
2. **Interior Fuse Box:** Usually found under the dashboard on the driver's side, this fuse box contains fuses for the vehicle's interior electronics, such as the audio system, lights, and power windows.
3. **Trunk Fuse Box (if applicable):** Some WRX models may also have an additional fuse box located in the trunk area, which might be connected to features like the rear lights or audio system.

Components of the Fuse Box

Understanding the components of the fuse box is vital for effective troubleshooting. Below are the key components you will find in a Subaru WRX fuse box.

Fuses

Fuses are the primary components of the fuse box, designed to protect electrical circuits. They come in various types and ratings, which are crucial for the proper functioning of your WRX.

- **Mini Fuses:** These are smaller and are used for circuits with lower amperage.

- Micro Fuses: Even smaller than mini fuses, these are often used in modern vehicles for compact electronic systems.
- Blade Fuses: Commonly used in many vehicles, including the Subaru WRX, these fuses are easy to replace.

Relay

Relays are electromagnetic switches that control larger electrical loads. They allow a low-power circuit to control a high-power circuit without the need for a heavy-duty switch.

- Fuel Pump Relay: Controls the fuel pump operation.
- Starter Relay: Engages the starter motor when the ignition is turned on.

Fuse Box Diagram

The fuse box diagram is an essential tool that shows the layout of the fuses and their respective functions. Typically printed on the inside of the fuse box cover, this diagram helps you identify which fuse corresponds to which electrical component.

Common Fuses and Their Functions

Below is a list of common fuses found in the Subaru WRX, along with their functions:

1. ECU Fuse: Protects the engine control unit, vital for engine management.
2. Headlight Fuse: Controls the functioning of the headlights.
3. Fuel Pump Fuse: Essential for the operation of the fuel pump.
4. Radio Fuse: Protects the audio system from electrical surges.
5. Power Window Fuse: Controls the operation of power windows.
6. ABS Fuse: Protects the anti-lock braking system's electronics.

How to Read the Fuse Box Diagram

Reading the Subaru WRX fuse box diagram is straightforward if you know what to look for. Here's how to do it effectively:

1. Locate the Diagram: Open the fuse box cover to find the diagram printed inside.
2. Identify the Fuses: Each fuse will be labeled with a specific number or letter, corresponding to its

position in the fuse box.

3. **Check the Amperage Rating:** The diagram will also indicate the amperage rating for each fuse. This is important for replacement purposes.
4. **Understand the Function:** Next to each fuse number, the diagram should provide the function or component that the fuse protects. This will help you identify which fuse to check when troubleshooting an issue.
5. **Replacement Information:** Some diagrams may also provide tips on replacing fuses, including the recommended type and amperage.

Steps to Replace a Blown Fuse

If you find that a fuse has blown in your Subaru WRX, it's essential to replace it promptly to ensure functionality. Here's how to do that:

1. **Identify the Blown Fuse:** Use the fuse box diagram to locate the fuse for the malfunctioning component.
2. **Remove the Fuse:** Use a fuse puller or a pair of needle-nose pliers to remove the blown fuse. Check to see if the wire inside is broken or melted.
3. **Check the Amperage:** Before replacing, ensure you have the correct amperage rating for the replacement fuse.
4. **Insert the New Fuse:** Carefully insert the new fuse into the correct slot. Make sure it is seated securely.
5. **Test the Component:** After replacing the fuse, test the electrical component to ensure it's functioning correctly.
6. **If It Blows Again:** If the new fuse blows shortly after replacement, it could indicate a deeper electrical issue. Consult a professional mechanic for further diagnosis.

Conclusion

Understanding the Subaru WRX fuse box diagram is an integral part of maintaining your vehicle's electrical system. Knowing the layout, components, and functionality of the fuse box can help you troubleshoot issues effectively and perform necessary repairs. Regular checks of the fuses can prevent electrical failures and ensure that your WRX runs smoothly. For any deeper electrical problems, don't hesitate to consult a professional. With proper care and knowledge, you can keep your Subaru WRX in peak condition for years to come.

Frequently Asked Questions

What is the purpose of the fuse box in a Subaru WRX?

The fuse box in a Subaru WRX houses various fuses that protect the electrical circuits in the vehicle, preventing damage from overloads and short circuits.

Where is the fuse box located in a Subaru WRX?

In a Subaru WRX, the fuse box is typically located under the dashboard on the driver's side and may also have a second fuse box in the engine compartment.

How do I read the fuse box diagram for my Subaru WRX?

To read the fuse box diagram, locate the diagram on the cover of the fuse box or in the owner's manual, which will show the layout and indicate which fuses control specific electrical components.

What should I do if a fuse in my Subaru WRX blows?

If a fuse in your Subaru WRX blows, you should replace it with a new fuse of the same amperage. Always check the reason for the blowout to prevent future occurrences.

What are common issues that can be caused by a blown fuse in a Subaru WRX?

Common issues from a blown fuse in a Subaru WRX include inoperable lights, malfunctioning power windows, or failure of the radio or other electronic accessories.

Can I modify the fuse system in my Subaru WRX?

While you can modify the fuse system, it is not recommended unless you have a thorough understanding of the vehicle's electrical system, as incorrect modifications can lead to electrical failures or fires.

[Subaru Wrx Fuse Box Diagram](#)

Subaru Wrx Fuse Box Diagram

Related Articles

- [story of life of pie](#)
- [swot analysis marketing plan example](#)
- [sugar sugar 2 hooda math](#)

[Back to Home](#)